

CREATING CHURCH AND THEATRE ORGAN REGISTRATIONS

THEATRE ORGAN REGISTRATION 3

Registration Description

This registration has a general theatre ensemble on the lower keyboard suitable for ensemble playing but can also provide an accompaniment for solo and ensemble playing on the upper keyboard. The upper sound has a brass voicing.

Preset Registration

Total Preset For - Theatre Registration Example 3

Arrangement By – Jeff Ormerod

Selectors		Sounds	Volume	Octave	Other Settings	
Selector	Sound	Volume	Octave	Wersichord	Sound Control Screen	
Upper 1	Theatre Organ *	80	-1			
Upper 2	Prinzipal 16	80	0		Sound Control Distance = 40	
Upper 3	TH Bold Brass	60	0			
Upper 4						
Lower 1	Theatre Organ *	70	0			
Lower 2	Dulciana	60	0		Sound Control Distance = 40	
Lower 3						
Pedal 1	Bourdon	70	0			
Pedal 2	Bass Flute	50	0			

Remarks

All other control parameters are in their default **Std Inst** settings

The *Prinzipal 16* and *Dulciana* sounds are taken from the Sakral Sound Package.